


Pneumatic Paving Breaker TPB-90 Part Diagram and Part Number



Symbol No.	Parts No.	Q' ty	Description
1	410241010	1	Cylinder
2	136301011	3	Cylinder Plug
3	410241041	1	Piston
4	410241150	1	Valve
5	410241190	1	Valve Chest
6	410241170	1	Valve Seat

7	410241200	1	Valve Guide
8	130401035	1	Valve Chest Dwel Pin
9	410241660	1	Plunger
10	130801040	1	Plunger Spring
11	410241480	1	Back Head
12	131105017	1	O-Ring 6227-17
13	136601011	2	Rubber Grip
14	410041E00	1	Throttle Pin
15	410201300	1	Throttle Valve Stem Guide
16	130801009	1	Throttle Valve Spring
17	410241311	1	Trottle Lever
18	410201330	2	Trottle Lever Pin
19	134905010	1	Oil Plug U3/4-10
20	134901001	1	Pipe Plug PP-2 PT 1/8
21	410241531	1	Front Head
22	130505048	1	Polyurethane Rubber Ball 3/4
23	131501015	4	Back Head Bolt
24	131301116	4	Spring Washer M16
25	410241510	4	Back Head Bolt Nut
26	410241591	1	Tappet Seat
27	410241581	1	Tappet
28	410239610	1	Steel Retainer
29	410241620	1	Steel Retainer Bolt
30	134601019	1	Hex Nylon Nut UNF3/4-16
31	131303048	1	Spring Washer W3/4
32	136301010	2	Steel Retainer Bolt Bushing
33	410241650	1	Steel Retainer Plunger
34	130801042	1	Steel Retainer Spring
35A	410271370	1	Air Connection Tube
35B	131103023	1	O-Ring S-29
36	410271390	1	Air Connection Nut
37	131102002	1	O-ring G-30
38	136801007	1	Air Inlet Screen
39	131501016	2	Front Head Bolt
40	410241550	2	Front Head Bolt Nut
41	410241560	2	Front Head Bolt Lock Washer
42	130801043	2	Front Head Bolt Spring
44A	410241572	1	Front Head Bushing 1-1/8"
44B	410245572	(1)	Front Head Bushing 1-1/4"